February 2020

## Structural Systems



## Basic Structural Terminology

# What is structural design?

- More than crunching numbers.
- Maintaining the balance, between safety, cost and durability.

R101.3 Purpose. The purpose of this code is to establish minimum requirements to safeguard the public safety, health and general welfare through affordability, structural strength, means of egress facilities, stability, sanitation, light and ventilation, energy conservation and safety to life and property from fire and other hazards attributed to the built environment.



## Structural Criteria

- •Based on climate and geographical location.
- •Includes wind, seismic, flood other environmental hazards such as roof ice dams and termites.

R301.2 Climatic and geographic design criteria. Building shall be constructed in accordance with the provisions of thi code as limited by the provisions of this section. Additiona criteria shall be established by the local jurisdiction and se forth in Table R301.2(1).



## Construction Systems

- •Platform
- •Balloon Framing

**R301.1.2** Construction systems. The requirements of this code are based on platform and balloon-frame construction for light-frame buildings. The requirements for concrete and masonry buildings are based on a balloon framing system. Other framing systems must have equivalent detailing to ensure force transfer, continuity and compatible deformations.

## **Platform Framing**


•The most common method in modern construction.

[RB] PLATFORM CONSTRUCTION. A method of construction by which floor framing bears on load bearing walls that are not continuous through the story levels or floor fram-



## **Balloon Framing**

- · Found in historical homes
- Sometimes used in portions of homes for added rigidity (great rooms, stairwells, gable-end walls, etc.)





**DESIGN CRITERIA** R301.1 Application. Buildings and structures, and part thereof, shall be constructed to safely support all loads System Performance including dead loads, live loads, roof loads, flood loads, snow loads, wind loads and seismic loads as prescribed by this code. The construction of buildings and structures in according to the construction of building to the construction of the construct dance with the provisions of this code shall result in a system that provides a complete load path that meets the require ments for the transfer of loads from their point of origin through the load-resisting elements to the foundation. Build-ings and structures constructed as prescribed by this code are

- ·Structural members do not work independently in light-frame construction. They are always part of a SYSTEM.
- •Two basic principles in system performance are:
- **Load Sharing**
- **Composite Action**

## Load Sharing

The strength comes from multiple elements sharing the load.




## Composite Action

The strength comes from the manner that the elements come together.


(glue, nails, joist spacing, grain direction, staggered joints, etc.)

# [RB] STRUCTURAL COMPOSITE LUMBER. Structural members manufactured using wood elements bonded together with exterior adhesives.



## Whole House Testing

- Whole House Testing or Full-House testing is becoming more popular and a crucial component in the development of many modern building products.
- It shows that the strength comes from the way the building is put together as a SYSTEM.
- · Buildings are only as strong as their weakest link.






## Tributary Area

• Is the portion of the load assigned to each member.

AM102.1 Footings. Support posts shall be supported by a minimum footing in accordance with Figure AM102.1(1) and Table AM102.1. Minimum footing depth shall be 12 inches (305 mm) below finished grade in accordance with Section R403.1.4. Tributary area is calculated as shown in Figure AM102.1(2).





## Load Path Analysis

- Used to minimize the material needed in the load-bearing member to support the design load.
- Load paths can be very complex, but the load path must be understood to determine tributary areas.

#### SECTION R301 DESIGN CRITERIA

R301.1 Application. Buildings and structures, and parts thereof, shall be constructed to safely support all loads, including dead loads, live loads, roof loads, flood loads, snow loads, wind loads and seismic loads as prescribed by this code. The construction of buildings and structures in accordance with the provisions of this code shall result in a system that provides a complete load path that meets the requirements for the transfer of loads from their point of origin through the load-resisting elements to the foundation. Buildings and structures constructed as prescribed by this code are deemed to comply with the requirements of this section.






### Deflection

- · The code sets limits on the maximum allowable deflection depending on the type of member involved.
- · Greater deflection is allowed in ceiling joists and rafters than in floor
- · Code Changes: Table R301.7 Deflection also applies to ceilings and exterior walls - wind loads.

R301.7 Deflection. The allowable deflection of any structure tural member under the live load listed in Sections R301. and R301.6 or wind loads determined by Section R301.2 shall not exceed the values in Table R301.7.



### Deflection

Generally, it is not necessary to calculate the deflection indicated in Table R301.7, since deflection for balloon or platform framing is typically accounted for in the prescriptive design tables of the code.

In other structural systems such as timber framing, deflection calculation is required.

STRUCTURAL MEMBER	ALLOWABLE DEFLECTION
Rafters having slopes greater than 3:12 with finished ceiling not attached to rafters	L/180
Interior walls and partitions	H/180
Floors	L/360
Ceilings with brittle finishes (including plaster and stucco)	L/360
Ceilings with flexible finishes (including gypsum board)	L/240
All other structural members	L/240
Exterior walls—wind loads <sup>a</sup> with plaster or stucco finish	H/360
Exterior walls—wind loads <sup>a</sup> with other brittle finishes	H/240
Exterior walls—wind loads <sup>a</sup> with flexible fin- ishes	H/120 <sup>d</sup>

ote: L = span length, H = span heigh

- For the purpose of the determining deflection limits herein, the wind loa

- d. Deflection for exterior walls with interior gypsum board finish shall be limited to an allowable deflection of H/180.
- e. Refer to Section R703.8.2.
- f. When floor spans exceed 20 feet, joists, built-up beams and trusses shall no

## Climatic and Geographic Design Criteria (R301.2)

- Climatic and geographic design criteria is to be determined by the local jurisdiction and inserted into Table R301.2(1).
- · This information should also be provided to the designer who should list it on the plans submitted for review.

ROOF	WIND	SEAIMIC DESIGN	SUBJECT TO DAMAGE FROM		WINTER	ICE BARRIER UNDERLAYMENT	FLOOD HAZARD <sup>b</sup>	AIR FREEZING	MEAN ANNUAL	
(psf)	(mph)	CATEGORY	Weathering <sup>a</sup>	Frost Line Depth	<u>Termite</u> <sup>c</sup>	TEMP	REQUIRED		INDEX	TEMP
20	Tables R301.2 (4) & (5)	Table R301.2(7)	Moderate	12"	Moderate- Heavy	Local	Local	Local	Local	Local

a. Weathering may require a hisher strength concrete or grade of masonry than necessary to satisfy the structural requirements of this code.
The grade of masonry units shall be determined from ASTM C34, C55, C6), C72, C90, C129, C135, C216 or C652.

b. The Intriscition shall fill in this part of the table with (at the date of the unstalctions) entire to the National Flood Insurance Program (date of adoptions of the first code or ordinance for management of flood hazard areas), (b) the date(s) of the currently effective FIRM and FBFM, or other flood hazard map adopted by the community, as may be amended.

c. Protection is required in all of North Curollina per Section 8218.

## **Exposure Categories**

- · Important when applying the provisions for wall sheathing, wood wall bracing, roof uplift resistance, and exterior wall and roof coverings
- · Siding, roofing, windows, skylights, exterior doors and overhead doors must be manufactured and installed to resist wind loads based on wind speed and exposure factors. (R301.2.1.4)


R301.2.1.4 Exposure category. For each wind direct tion considered, an exposure category that adequately reflects the characteristics of ground surface irregulari ties shall be determined for the site at which the building or structure is to be constructed. For a site located in th






## Uplift

- Upward pressure caused by the ground, wind or surface water, etc.
- · Can be resisted by:
- ·Dead Loads
- Mechanical connectors (straps, hurricane ties, screws, threaded rods)
- Sheathing



## Irregular Buildings

- Buildings with offsets in braced wall lines, arrangement of openings, cantilevers, and/or dissimilar materials in braced wall lines.
- Irregular townhome buildings in SDC C require engineering.
- Mecklenburg is no longer SDC C.




Conventional Design vs.
Engineered Design




# Conventional Design

- RESIDENTIAL CODE
- Is prescriptive. Set by the NCRC.
- · Contains:
- •Span tables
- · Pre-defined details
- Pre-defined options



## Conventional Design

- Most used method in single family homes.
- 90% of our residential projects are single family homes.
- Easy for builders & inspectors NO Registered Design Professional required.



R301.13 Engineered design. Where a building of otherwise conventional construction contains structural elements exceeding the limits of Section R301 or otherwise
not conforming to this code, these elements shall be
designed in accordance with accepted engineering practice. The extent of such design need only demonstrate
compliance of nonconventional elements with other applicable provisions and shall be compatible with the performance of the conventional framed system. Engineered
design in accordance with the International Building Code
is permitted for buildings and structures, and parts thereof,
included in the scope of this code.



## Engineered Design

- The design is not constrained to fit within the limitations of prescriptive design.
- Conventional details can still be used where they are applicable.
- Engineers can design specific design components while using prescriptive requirements for the rest of the building.

Engineered design is typically required when using:

- · Long spans
- · High Hazards (wind, flood, seismic)
- · Unconventional Products
- · Bad soils
- · High end features

 $(at riums,\, high\text{-}tech\,\, appliances,\, etc.\,\,$ 

- Foundation walls exceeding 48" unbalanced fill with no lateral support at the bottom or hydrostatic pressure. (code change)
- Exceeding max. story height.
  - · Wood frame & SIP 11'-7"
  - Masonry 13'-7".

### In any case...

## The Design Team MUST know and follow:

- •Code requirements
- Amendments
- ·Referenced standards
- Local Interpretations

## Alternative Provisions (R301.1.1-R301.1.3)

- · AF&PA Wood Frame Construction Manual (WFCM).
- AISI Standard for Cold-formed Steel Framing—Prescriptive Method for One-and Two-Family Dwellings (AISI S230).
- ICC-400 Standard on the Design and Construction of Log Structures.
- · AAMA/NPEA/NSA 2100 for sunrooms.
- · Accepted engineering practice
- · Engineered design in accordance with the IBC.

# Accepted engineering practice

#### May include:

- A design prepared by a licensed professional engineer or architect.
- Evaluation reports from the ICC Evaluation Services® ICC ES®.
- Manufacturer's information containing test results or case studies.
- Other materials within the judgment of the building official.



## Other Referenced Standards:

- Wood Frame Construction Manual (AWC) (R301.1.1)
- NDS -National Design Specifications for Wood Construction (AWC)
- ACI-318 Building Code Requirements for Structural Concrete (ACI)
- ACI-530 Building Code Requirements for Masonry Structures (ACI)
- ASCE 7-10 Minimum Design Loads for Buildings and Other Structures.

# When reviewing structural drawings...


- Make sure they show 100% complete construction documents.
- Remember that structural notes take precedence over specifications. (exception to the norm).
- · Plans should always have dimensions.

## Design Loads

## Design Loads

Are the maximum amount of force the structural system is designed to resist.


- ·Vertical Loads
- ·Horizontal Loads




## Vertical Loads

- $\cdot$ Dead
- •Live
- •Snow
- $\bullet Wind\ uplift$
- •Seismic and wind (overturning)
- •Seismic (vertical ground motion)












Table R30 MINIMUM UNIFORMLY DIST (IN POUNDS PER SQL	RIBUTED LIVE LOAD	DS
USE	LIVE LOAD	
Uninhabitable attics without storage b	10	
Uninhabitable attics with limited storage b, g	20	т٠
Habitable attics and attics served with fixed stairs	30	Live
Balconies (exterior) and decks <sup>e</sup>	40	Loads
Fire Escapes	40	(R301.5)
Guards and handrails d	200 h	(2100 210)
Guard in-fill components <sup>f</sup>	50 h	
Passenger vehicle garages <sup>a</sup>	50 a	
Rooms other than sleeping rooms	40	
Sleeping rooms	30	
Stairs	40 °	






## $Ultimate\ Wind\ Speed\ {\tiny (Code\ Change\ 301.2.1.3)}$

- Wind speed terminology has changed, but the requirements are the same.
  - · Basic Wind Speed was 90 mph
  - · Ultimate Wind Speed is 115 mph
- Ultimate Wind Speed was introduced because most standards are facing out Allowable Stress Design in favor of Load Resistance Factored Design
- Basic speed numbers are still necessary to evaluate many product.




## Wind Resistance (Code Change R316.8)

- Where foam plastic insulation is used as *exterior wall* sheathing on framed wall assemblies, it shall comply with Section R316.8.
- ASTM C578 & C1289
- · SBCA FS100.




Continuous Insulation Sheathing






## Flood Resistant Construction (Code Change) R322

- · ASCE 24 may now be used as an alternate.
- It requires structures to be elevated above the Flood Insurance Rate Map (FIRM) elevation.
- Allows parking, building access & storage is allowed below the F.E. if it has flood openings per R322.2.2.1. (Doors and windows don't count).





#### Seismic Failures

- · A soft-story building is a multi-level structure located over a ground level with large openings, typically parking.
- · During an earthquake the heavier to puts disproportionate stress on the carport causing collapse.
- · Buildings may be retrofitted with steel frames, reinforced walls or braces drilled into the foundation.



## Seismic Activity in NC

· North Carolina has its share of earthquakes, but large, damaging seismic events are



- Most minor earthquakes (< 3.0) occur unnoticed and are a normal process that allows the earth to ease built-up geological strain
- · Although strong earthquakes here in North Carolina are rare, proper construction techniques needs to be followed as required by code. An earthquake of magnitude 5.0 or greater could cause major damage.

#### Seismic Design Category (Code Change)

- · Mecklenburg County was dropped from Category C to B.
- · Therefore, anchorage not required for townhomes for:
  - · Interior nonstructural walls and partitions
  - Cantilevered elements
  - · Parapets
  - · Curtain wall and precast cladding
  - · Suspended Ceilings
  - · Cabinets
  - · MEP Attachments



Standard Responsibilities for Structural Code Compliance



## Contractor

Compliance for items not visible to the inspector, are the Contractor's Responsibility.

## Registered Design Professional

- •On plans that are designed & sealed by an architect or engineer: MCCE will not perform specific calculations, such as confirming that the proper amounts of wall bracing are provided.
- •This is the RDPs responsibility.

## Inspector

- If non compliant items, such minimum bracing amounts as are found on the field, the condition shall be corrected by the Field Inspector as required by code.
- An N.O.V. may be issued.

#### Plan Reviewer

- Plan Reviewers shall require engineers to specify all information necessary to execute the project, such as:
  - · the bracing method.
  - ·locations of braced wall lines & panels.
  - the method of attachment for braced wall panels.

February 2020

## Wall Bracing



This presentation is partially based on A Guide to the 2015 IRC Wood Wall Bracing Provisions, with NC amendments.



Why is it important to understand it?

The better the code is understood, the more likely it is to be correctly applied.

The more you know, the easier your job is.

## Wall Bracing

(R602.10

- Since the exterior walls of a structure are typically made up of repetitive vertical studs, wall bracing is required to give it strength against wind or earthquake forces.
- The bracing, resists forces that may cause the structure to "rack," twist or shift.





## Bracing is simple, Right???

- •APA & ICC wrote a 324 page book explaining the braced-wall requirements called:
- "A Guide to the 2015 IRC Wood Wall Bracing Provisions."

So... no, it is not that simple.

## History of wall bracing

- Wall bracing requirements are not new to the codes.
- In fact, several of the current bracing methods, including let-in bracing, diagonal wood boards and Portland cement plaster, reflect conventional construction practices that were common over 50 years ago.

# **Development of wall bracing** 2000

The 2000 IRC introduced several new bracing provisions and methods:

- Minimum bracing percentage
- · Maximum braced wall line spacing
- · Continuous sheathing
- Portal frames
- Separate bracing requirements for wind and seismic

## **Development of wall bracing** 2012

- The 2012 IRC reworded the bracing section to make it more understandable and consistent.
- The 2012 IRC added the Simplified Method and 2012 NCRC incorporated it as an amendment.


# Development of wall bracing - 2015

- The 2015 IRC added a few additional tweaks to wall bracing due to changes in proprietary hold-down straps.
- The 2015 IRC also expands the use of Simplified Wall Bracing provisions
- The 2018 NCRC remained the same.


# Why are code updates important?

- •We don't build like we used to.
- •We now see larger homes, larger openings and new materials.











Insufficient (or non-existent) anchorage of the walls to the foundation caused the entire structure to slide approximately 6 feet off the foundation. (Photo taken after a tornado in Fayetteville, North Carolina.)

## Connection failure



A closer look at the foundation shows negligible connection of the sill plate to the foundation. The framer attempted to use nails to make this connection; however the nails are mostly bent at the tip and did not significantly penetrate the masonry foundation walls. (Photo taken after a tornado in Foyetteville, North Carolina.)

## Important Terminology

#### [RB] BRACED WALL CONTINUOUSLY SHEATHED.

A braced wall with structural sheathing applied to all sheathable surfaces including the areas above and below openings.

[RB] SHEAR WALL. A general term for walls that are designed and constructed to resist racking from seismic and wind by use of masonry, concrete, cold-formed steel or wood framing in accordance with Chapter 6 of this code and the associated limitations in Section R301.2 of this code.


## **Definitions**


[RB] BRACED WALL PANEL. A full-height section of wall constructed to resist in-plane shear loads through interaction of framing members, sheathing material and anchors. The panel's length meets the requirements of its particular bracing method, and contributes toward the total amount of bracing required along its braced wall line in accordance with Section R602.10.1.

Put simply, the term "braced wall panel" describes a code-qualified bracing element. The origin of the name "panel" most likely lies in the fact that most of the recognized methods of bracing use panel-type products; however, the term is somewhat of a misnomer. "Panel" can actually be used to describe a wall "section," "segment," or "unit." Even let-in bracing is often referred to as a bracing panel. As such, the terms braced wall panel, braced wall section, braced wall segment and bracing unit are often used interchangeably.

- · Wall bracing is meant to resists racking.
- · As little as 3/8" of racking can make doors stick.

## Racking





• A horizontal or nearly horizontal system acting to transmit lateral forces to the vertical resisting elements.

Diaphragm

• When the term "diaphragm" is used, it refers to horizontal bracing systems. e.g. floor or roof.



The loss of sheathing compromises the strength of the roof diaphragm. It is likely that the complexity of the connection between the roof sheathing and the step-down trusses has resulted in poor resistance to negative pressure. (Photo taken after a tornado in Foyetteville, North Carolina).

[RB] DIAPHRAGM. A horizontal or nearly horizontal system acting to transmit lateral forces to the vertical resisting elements. Where the term "diaphragm" is used, it includes horizontal bracing systems.

## Continuity

R602.10.3 Continuous sheathing.

- Exterior walls shall be sheathed on all sheathable surfaces including infill areas between braced wall panels, above and below wall openings, and on gable end walls.
- Continuous wall bracing must extend up the gable end walls if present.
- This ensures that the load path is continuous from the foundation to the roof diaphragm.

What is the difference between a Shear Wall and a Braced Wall?

# Shear Wall is engineered.

- · Wood structural panels
- May have pre-engineered hold downs in addition to anchor bolts.
- Designed per: IBC ♠ASCE-7 ♠ SDPWS

# Braced wall is prescriptive.

- · Per the IRC
- · Braced Wall Panels
- · Anchor bolts.

# Horizontal Loads can be resisted by:

- ·Braced wall panels
- •Engineered shear walls
- •Portal frames

### Shear Wall

- This is a general term used for walls that are designed and constructed to resist racking from seismic and wind by use of masonry, concrete, cold-formed steel or wood framing.
- They are designed in accordance with Chapter 6 of the code and the associated limitations in Section R301.2 of the code (seismic).

#### Braced Wall Panel

•A full-height section of wall constructed to resist in-plane shear loads through interaction of framing members, sheathing material and anchors.



## Reviewing Bracing Methods

# Step 1: Identify the bracing method used □ 1. Isolated panel bracing (R602.10.2) □ 2. Continuous sheathing (R602.10.3) □ 3. Engineered design (R602.10.5) □ 4. 2015 IRC, Section R602.10 □ 5. SR-102 as published by APA


## Portions of the system (R602.10)

Portions of the building that can not comply with the IRC may be engineered. t.

Where a building, or portion thereof, does not comply with Section R602.10.2, R602.10.3, or R602.10.4, those portions shall be designed and constructed in accordance with Section R602.10.5

R602.10.5 Wall bracing by engineered design. Design using bracing materials and methods listed in Table R602.10.1 or approved alternative materials and methods shall be permitted and shall comply with accepted engineering practice. Accepted engineering practice shall include the following:

- 1. Design in accordance with Section R301,
- Design equivalent to the analysis basis of the provisions in Sections R602.10.2. R602.10.3. and R602.10.4. including determination of design loads, design unit shear values, and bracing amounts.




#### Notes

#### Notes

- a. Alternative bracing materials and methods shall comply with Section 105 of the North Carolina Administrative Code and Policies, and shall be permitted to be used as a substitute for any of the bracing materials listed in Table R602.10.1 provided at least equivalent performance is demonstrated. Where the tested bracing strength or stiffness differs from tabulated materials, the bracing amount required for the alternative material shall be permitted to be factored to achieve equivalence.
- b. All edges of panel-type wall bracing required from Tables R602.10.1 and R602.10.3 shall be attached to framing or blocking, except GB bracing horizonts joints shall not be required to be blocked when joints are finished.
- c. Two LIB braces installed at a 60° angle shall be permitted to be substituted for each 45° angle LIB brace.
- d. For 8-foot (2483 mm) or 9-foot (2743 mm) wall height, brace panel minimum length shall be permitted to be reduced to 36-inch (914 mm) or 42-inch length (1067 mm), respectively, where not located adjacent to a door opening. A braced wall panel shall be permitted to be reduced to a 32-inch (813 mm) length when studia at each end of the braced wall panel are anchored to foundation or framing below using hold-down device with minimum 2,800 pounds design tension capacity. For detached single story garages and attached garages supporting roof only, a minimum 24-inch (610 mm) brace panel length shall be permitted on one wall containing one or more garage door oroenings.
- e. Bracing methods designated CS-WSP and CS-SFB shall have sheathing installed on all sheathable surfaces above, below, and between wall openings.
- For purposes of bracing in accordance with Section R602.10.2, two portal frame brace panels with wood structural panel sheathing applied to the exterior fac of each brace panel as shown in Figure R602.10.1 shall be considered equivalent to one braced wall panel.
- g. Structural fiberboard (SFB) shall not be used in portal frame construction.
- h. No more than three portal frames shall be used in a single building elevation.
- . CS-WSP and CS-SFB cannot be mixed on the same story. Gable ends shall match the panel type of the wall below.


### Isolated

- Used in separate locations along a braced wall line.
- Nonstructural sheathing can be used in areas of the wall where bracing is not required. (no blocking required)




## Nailing


- Edge nailing can be 3"-7" depending on the method. It's job is to resist racking.
- Field nailing can be 6-12" depending on the method. It's job is to resist buckling.





### LIB


- The effectiveness of let-in bracing depends on the craftsmanship of the framer when cutting the notches for the 1x4 brace.
- There are some metal alternate products available (ESR required).
- Both have limited structural capabilities, works very well in small homes.











# PCP Portland cement plaster Stud spacing behind Portland cement plaster shall not exceed 16\* 48\* to 58\* Stud spacing behind Portland cement plaster shall not exceed 16\*

## PF (top defects)

- •It is important to <u>include the door transom</u> in the calculation!
- •A door is not the same as a window when doing the wall/height ratio calculation.
- Not providing reinforcement on stem walls  $\leq 48$ ". (other methods too)

#### Continuous

- The whole wall line is sheathed, including above and below openings and at gable ends.
- The whole wall line is blocked at horizontal joints.
- Requires less bracing and permits the use of narrower bracing panels

### CS-WSP

- · Provides the greatest bracing capacity
- All sheathable surfaces of the exterior walls are required to have sheathing, even if the design calls for an interior braced wall line & panels.
- CS-WSP panels next to openings shall use the largest opening on either side of a panel to determine min panel size per Table R602.10.1;
- Include transoms in the opening height if present.


## CS-SFB

- Continuously sheathed structural fiberboard.
- •Other bracing methods may not be used in a Method CS-SFB wall line.

## Blocking (Per MCCE)

- ·Isolated Panel Bracing:
- Blocking at horizontal joints shall not be required in wall segments that are not counted as *braced wall panels*.
- •Continuous sheathing methods (CS): Every panel is a braced wall panel and shall be blocked.

## **Portal Frames**



## **Portal Frames**


- With a few small openings, providing bracing it is easy.
- Large openings such as garage doors, can complicate the design.
- This is where portal frames come into play.





## Portal Frame Garage

▶ In a portal frame, the header extends past the opening and is tied to its wall with overlapping plywood or OSB to stiffen the joint.

► (R602.10, R602.12)







## 3. Common defects

- ▶ Nailing details are important.
- ► Heavy nailing is a critical to keep the corner joint stiff and prevent racking. (more nails than required will split the wood)
- ► A 1,200 SF. house may need up to 10,000 nails



## **ANCHORAGE**

## Foundation $\underset{\tiny R403.1.6}{\text{anchorage}}$

• The wood sill plate must be anchored to the foundation with anchor bolts spaced a maximum of 6 feet on center.


## Foundation anchorage R403.1.6

- There must be a minimum of two bolts per sill plate section.
- 6 Ft. O.C. and 12" at the

## Foundation anchorage


R403.1.6


• There shall be a minimum of two bolts per plate section with one bolt located not more than 12 inches or less from each end of the plate section.



# $\begin{array}{c} Foundation \\ anchorage \\ {}_{\text{R403.1.6}} \end{array}$

- Bolts should be at least 1/2 inch in diameter and should extend a minimum of 7 inches into the concrete or masonry foundation.
- A nut and washer is required on each bolt to hold the plate to the foundation.






# $\begin{array}{c} Foundation \\ anchorage \\ {}_{\text{R403.1.6}} \end{array}$

- Masonry stem walls 48" or less in length that support any braced wall panels (BWP) shall be reinforced per R602.10.5.3
- This includes stem walls supporting any BWPs including the portal frame (PF) bracing method.


# Stem Walls The reinforcement details in Figure R602.10.4.3 are appropriate for masonry stem walls that are up to 4 feet in length and not more than 4 feet in height.


# Stem Walls If the masonry stem walls are taller than 4 feet, an engineered design of the reinforcement is required. Stem was a source of the reinforcement is required. \*\*COVIE MAY DE TON INCIDENT STEM WALL RENO CREAM WITH 1-44 DATE OF THE WALL RENO CREAM WI




## End Conditions

- The code offers five, end conditions which are intended to provide equivalent hold-down strength as is required in the IBC.
- They only apply to continuous sheathing.








March 2020

## Fire Safety



## Fire Safety

- Most US fires occur in residential buildings, particularly one- and two-family dwellings.
- These fires account for more than 80% of all deaths from fire in residential uses (including hotels, apartments, dormitories, etc.) and about two-thirds of all fire fatalities in any type of building.
- One- and two-family dwellings also account for more than 80% of residential property losses and more than one-half of all property losses from fire.



# Basic Fire Safety provisions

- Smoke alarms
- Egress
- Fire Separation Distance (FSD)




Smoke alarms

Where are smoke alarms required?



- Each sleeping room.
- •Right outside the sleeping rooms.
- •Basements and habitable attics



Smoke Alarms (R314.6) Power

• Primary power from house wiring with battery backup.



Smoke Alarms (R314.1.1) Listing

•UL 217



## Smoke Alarms (R314.4) Interconnection

- Must be interconnected
- Interconnectivity may be wired or wireless.



## Smoke Alarms Required (R314.2.2)

## Major Renovations & interior additions:

• Permanent wiring is required.



# Smoke Alarms Required (R314.2.2)

#### **Minor Building Renovations:**

- A smoke alarm is required. Battery power may be provided.
- Plumbing or mechanical work in existing dwellings also does not trigger the smoke alarm requirements.



### Fire Alarms (R314.7)

- Fire alarm systems shall be permitted to be used in lieu of smoke alarms.
- Fire alarms are most often seen in combination with home security systems.



## Residential Sprinklers

- Not required by the NCRC.
- Optional: Regulated by NFPA 13D or P2904.



## Residential Sprinklers Differences

	13D	13R
	Quickest response.  Primarily for life safety (not property protection)  Partial coverage. (not attics, closets, bathrooms, garages, concealed spaces, etc.)  No mixed use.  One- and two-family dwellings and townhouses.  Maximum three stories + attic.	<ul> <li>Quick-response.</li> <li>Primarily for life safety (not property protection)</li> <li>Partial coverage. (not attics, closets, bathrooms, garages, concealed spaces, etc.)</li> <li>No mixed use.</li> <li>Apartments, hotels, motels, dormitories &amp; 4 story townhomes.</li> </ul>
		Maximum four stories.
•	Water supply duration. (10min). Domestic water supply, a water well, an elevated storage tank, or approved tank allowed (or any combination). No backflow device.	Water supply duration. (30 min)     Approved water pressure & Backflow device.
•	PEX and CPVC pipe allowed.	CPVC and metallic pipe allowed.

Section R302 -Fire Resistant Construction



## Fire Separation Distance (FSD) See Ch.2 Definition


- ·Limits the spread of fire to protect property and occupants
- •Provides time for firefighting.





## Exterior wall protection (R302.1)

• Exterior walls or projections:

- Windows or doors:
- < 3 ft. = 1 hr. req.
- < 3 ft. = not permitted







## Accessory Dwelling Units and Temporary Health Care Structures

• Building Code requirements are completely different from zoning requirements.



## Basic building requirements for Accessory Dwelling Units and Temporary Health Care Structures:

#### ADU

- Attached ADU: This setup is similar to a duplex with no connectivity between units. 1 hr. fire separation is required and a separate address shall be required.
- Detached ADU: Is considered a second building in the same lot. A 3'-0" min. fire separation distance is required.
- Connected ADU: An ADU directly connected to the main structure (door or stair) is considered an extension of the primary residence and no fire separation is required.

#### Temporary health care structures

• The unit must be assembled off-site and built to the standards of the State Building Code for Manufactured Homes. It must be no more than 300 gross square feet. It can NOT be placed on a permanent foundation.

## Basic <u>zoning requirements</u> for Accessory Dwelling Units and Temporary Health Care Structures.

#### · ADU

A second dwelling unit located within the principal detached dwelling or within a separate accessory structure. The unit must include both kitchen and bathroom facilities and be intended for use as a year-round residence. Other restrictions apply when located in a mixed-use development, within a principal single family home, or within an accessory structure.

#### · Temporary health care structures

A manufactured home placed on a single family home lot. Must be owned or occupied by a qualified care-giver and the accessory structure is occupied only by the impaired person. The accessory structure must comply with all setbacks and any maximum floor area ratio limits that apply to the primary residential structure. The structure may be required to connect to any water, sewer, and electric utilities serving the property. Only one accessory temporary family care structure is allowed per lot. Other zoning requirements that are applicable to all other accessory structures in that zoning district may also be applied. No signage regarding the presence of the structure is allowed. The structure must be removed within 60 days after care-giving on the site ceases.

## Soffit Protection


- Soffits with a FSD <3 ft. Require one-hour fire protection on the underside.
- Soffits with a FSD <10 ft. Must be protected per sections R302.1.1 & R302.1.2.



## Townhomes

R302.3

- 2 hr. continuous separation (foundation to roof) required between unsprinklered townhomes.
- Electrical installations are allowed on the common wall.
- Plumbing or mechanical equipment, ducts or vents are <u>NOT allowed</u> on the common wall.



#### There are 4 basic conditions for installing standard electrical boxes on rated walls. (Exception #1)

#### Membrane Penetrations (R302.4.2)

R302.4.2 Membrane penetrations. Membrane penetrations shall comply with Section R302.4.1. Where walls are required to have a fire-resistance rating, recessed fixtures shall be installed so that the required fire-resistance rating will not be reduced.

#### Excentions


- Membrane penetrations of not more than 2-hour fire-resistance-rated walls and partitions by steel electrical boxes that do not exceed 16 square inches (0.0103 m²) in area provided that the aggregate area of the openings through the membrane does not exceed 100 square inches (0.0645 m²) in
- 2 does not exceed 100 square inches (0.0645 m²) in any 100 square feet (9.29 m²) of wall area. The annular space between the wall membrane and the box shall not exceed ½ inch (3.1 mm). Such boxes.
- annular space between the wall membrane and the box shall not exceed <sup>1</sup>/<sub>8</sub> inch (3.1 mm). Such boxes on opposite sides of the wall shall be separated by one of the following:
  - 1.1. By a horizontal distance of not less than 24 inches (610 mm) where the wall or


- partition is constructed with individual noncommunicating stud cavities.
- 1.2. By a horizontal distance of not less that the depth of the wall cavity where the wal cavity is filled with cellulose loose-fill rockwool or slag mineral wool insulation
- By solid fireblocking in accordance with Section R302.11.
- 1.4. By protecting both boxes with *listed* putty
- 1.5. By other listed materials and methods.
- 2. Membrane penetrations by listed electrical boxes of any materials provided that the boxes have been tested for use in fire-resistance-rated assemblies and are installed in accordance with the instructions included in the listing. The annular space between the wall membrane and the box shall not exceed 1/s inch (3.1 mm) unless listed otherwise. Such boxes on opposite sides of the wall shall be separated by one of the following:
  - 2.1. By the horizontal distance specified in the listing of the electrical boxes.
  - By solid fireblocking in accordance with Section R302.11.
  - By protecting both boxes with listed putty pads.
- 2.4. By other *listed* materials and methods.
- The annular space created by the penetration of a fire sprinkler provided that it is covered by a metal escutcheon plate.


#### Acoustical Fire Caulk

- · Question: Is acoustical fire caulk allowed?
- **Answer:** YES. Acoustical sealant is often applied on area separation walls to create an air barrier.
- An air barrier is an <u>optional feature</u> on Area Separation Walls designs. It prevents air leakage, noise transmission, air whistling and dust collection.










· Question: Are H-studs allowed in area separation walls instead of the C channels? · Answer: NO. Last year some illustrations of details U336 and U347 were showing that H studs can
be used horizontally at 24" o.c. We contacted US Gypsum, National Gypsum and UL
and they all confirmed that those drawings were incorrect, and that the assembly was
not tested using horizontal H-studs. The drawings are now corrected and GA has
published a document explicitly saying to use back-to-back C-runners only, which are
designed to firsting of the restrict H study. designed to friction-fit the vertical H studs.) · Refer to the revised UL details and/or document GA-620-2019. GA-620-2019 GYPSUM AREA SEPARATION FIREWALLS Note: Refer to manufacturer's installation instructions for specific limiting heights and clip spacing requirements for walls exceeding 44' (13 400 mm) in total height. 12. Begin the next course of the Gypsum Area Separation Firewall by attaching a 2" (51 mm) C-runner (with legs up) to the previously installed top C-runner of the lower course. This back-to-back Crunner installation allows for the progressive erection of the Gypsum Area Separation Firewall one floor at a time. Secure the two C-runners together with two 3/8" (10 mm) Type S pan head screws 24" (610 mm) o.c. Stagger back-to-back C-runner joints a minimum of 12" (300 mm). Note: Always use back-to-back C-runners between courses in Gypsum Area Separation Firewalls. Do not substitute a single H-stud for the specified back-to-back C-runners.


- Question: What can I do about a damaged rated wall after it has passed inspection?
- Answer: This happens all the time, right after a wall passes inspection, another trade comes in and damages it. So instead of replacing the whole panel or getting an engineering judgment, the inspector could accept the GA patch method (at his discretion).
- · Refer to document GA 225-2019.
- <u>NOTE:</u> For a multilayer assembly the gypsum panel joints are staggered from one layer to the next. The repair joints should not line up from one layer to the next. To accommodate that requirement, the base layer repair patch should be smaller than the face layer.



## Townhouse Roof protection:

#### **Options:**


- 1. A 30-inch-high parapet (2hr. rated).
- 2. Fire protection for a distance of 4 feet on each side of the separating wall.



# Townhouses without parapets


Roof penetrations are prohibited within 4 ft. of the separating wall:

- Skylights Exhaust outlets
- Roof windows
  - · Air intakes
- Gas vents Ridge vents
- Plumbing Roof vents vents



# Townhouse roof separation (R302.2.2.2-#3)

•Townhouse separation for roofs with greater than 30-inch height difference.



# Roof protection

For townhouses without parapets, roof penetrations are prohibited within 4 ft. of the separating wall:

- Skylights
- · Air intakes
- Roof windows
- · Ridge vents
- · Gas vents
- · Roof vents •
- Plumbing vents
- Exhaust outlets



## Additional Soffit Protection for Townhomes. (R302.2.5)

- •Wood sheathing is  $\sqrt[34]{}$  (not  $\sqrt{23}/\sqrt{32}$ ").
- Vents are not allowed within 4 ft. of fire walls.



## Overhang Protection for Townhomes. (R302.2.6)


Up to 12" overhangs may encroach the property line if:

- 1. The rated wall is tight to the roof deck.
- 2. Eaves are non-combustible or FRT.
- 3. Eaves have 5/8" Type X GWB or equivalent on the underside.




# Duplex separation (horizontal or vertical)

•One-hour fireresistance-rated separation between the dwelling units of a twofamily dwelling, continuous to the exterior walls or roof.



# Duplex separation alternative


- %-inch Type X gypsum board ceiling & the framing supporting the ceiling is protected with ½" gypsum. AND
- A½-inch gypsum board draft stop in the attic area.




## Through Penetrations (R302.4.1)

#### Exceptions:

- •1. Concrete grout or mortar can be used in on concrete or masonry walls.
- •2. Materials per ASTM 119 or UL 263.







## Membrane Penetrations (R302.4.2)

#### Exceptions:


- •1. Concrete grout or mortar can be used in on concrete or masonry walls.
- •2. Approved materials per ASTM 119 or UL 263.








# Dwelling-garage fire separation. R302.6

- $\frac{1}{2}$ -inch GWB required.
- 5%-inch Type X GWB ceiling if there is a habitable room above.
- The ceiling's bearing walls require ½-inch GWB on the interior surface.
- Sleeping rooms require 20-min. door <u>or</u> approved equivalent.












- •Open storage = no protection.
- •Enclosed storage = ½" GWB required on the enclosed side.



## Foam Plastic (R16.4)

Must be isolated from the dwelling by a ½" GWB or an equivalent thermal barrier.

• See exceptions for attics and crawlspaces R316.5.3 & R316.5.4. entered only for maintenance or repairs




# Flame Spread Index R302.9

- · Class C required.
- Does not apply to picture mold, chair rails, baseboards, handrails, wallpaper etc.




## Insulation R302.10.1


- Insulation, including facings used as vapor retarders or as breather papers, must be class A.
- If the paper is in contact with a material, there is no airspace to pose risk and Class A is not required.
- Cellulose insulation is regulated by CAN/ULC S102.2, SDI must be < 550.
- · Plastics are regulated by R316.





# $Fireblocking \ {\tiny R302.11}$


• Building materials installed to resist the free passage of flame to other areas of the building through concealed spaces.















# Manufactured Fireplaces & Chimneys

- · Listed per UL 127.
- Hearth extension per manufacture's specifications.
- 30 degree max. offset.
- · No more than 4 elbows.



# Firestop R1004, R1005

Q: The flue manufacturer states that you can't put firestopping caulk at ceiling levels. Because expansion and contraction is necessary. Do we leave an opening?



**A:** The manufacturer is correct per UL 127-7.3 an opening is required.

However, per UL 127-7.1.4. "The construction of a fireplace shall not void the firestopping required between spaces of a building when the fireplace and its chimney are installed in accordance with the manufacturers instructions."

So what can we do? We may use rockwool. It is non-combustible and allows expansion and contraction.

NOTE: Review the manual. Some appliances may require 1-36 inches of clearance to combustible materials.

# Questions?

March 2020

Home Safety



1. Room Areas

Minimum area

Overcrowding creates unhealthy and unsafe living conditions, such as:


- Moisture accumulation.
- Odors.
- Disease transmission.
- Inadequate ventilation.




Minimum
Dimensions
R304-1, R304-2


• 70 sf. min. for habitable rooms other than kitchens. (new).


• The smallest dimension shall be 7 ft. min. (except kitchens).




















NC Department of Insurance

Office of the State Fire Marshal - Engineering Division 1202 Mail Service Center, Raleigh, NC 27699-1202 919-647-0000

#### **Exterior Egress Door Dimensions**

Code: 2018 Residential Code

Date: April 9, 2019

Section: R311.2

# Exterior egress

R302.7, R311.1

door

#### Ouestion:

Section R311.2 specifies the requirements for the minimum dimensions of at least one exterior egress door, but other exterior doors are not required to comply with the minimum dimensions. Are other exterior egress doors required to meet any minimum dimensions?

Yes. Exterior egress doors, in addition to the one required, must meet the 78 inch minimum height requirement but are not required to meet the 32 inch minimum width. This minimum height dimension is required to be maintained in exterior egress doors to provide the inherent feeling of safety that a door utilized for egress should afford. Other exterior doors, such as a balcony access or ornamental opening, utilized in non-egress applications that are not intended for use in the evacuation of an occupied space are not required to meet the minimum dimensions.

#### Floors and Landings at exterior doors R311.3

- There shall be a landing or floor on each side of each exterior door.
- The width of each landing shall be not less than the door served.
- Every landing shall have a dimension of not less than 36" measured in the direction of travel.
- The slope at exterior landings shall not exceed 1/4 unit vertical in 12 units horizontal (2 %).

Floors and Landings at exterior doors R<sub>311.3</sub> exception

#### French balcony exception:

R311.3 Floors and landings at exterior doors. There shall be a landing or floor on each side of each exterior door. The width of each landing shall be not less than the door served. Every landing shall have a dimension of not less than 36 inches (914 mm) measured in the direction of travel. The slope at exterior landings shall not exceed 1/4 unit vertical in 12 units horizontal (2 percent).

Exception: Exterior balconies less than 60 square feet (5.6 m2) and only accessible from a door are permitted to have a landing less than 36 inches (914 mm) measured in the direction of travel.



#### Required on both sides of the door. The landing must Landings at be as wide as the exterior egress door & 36" deep min. doors A step down is R311.3 allowed IF the door swings in. Exception: The exterior landing or floor shall be not more than $8 \frac{1}{4} a$ inches (210 mm) below the top of the threshold provided the door does not swing over the landing or floor.

Landings at exterior non-egress doors

\*\*The floor or landing on either side of the door is permitted to be 8 1/4" inches below the top of the threshold.

\*\*The door may swing in either direction

\*

Landings at exterior non-egress exterior doors

R311.3.2 exception

A landing is not required outside IF the door swings in.

Storm & screen doors shall be permitted to swing over exterior stairs and landings.

Means of egress
R311.6

Hallways:

• The width of a hallway shall be not less than 3 ft. measured from the finished surface of the walls.

Means of egress

## Interior egress doors:

- Size: 2'-6" x 6'-8" (nominal)
- Readily openable (i.g. no double-keyed dead bolts).



Note: This is a Mecklenburg County Code Interpretation, not a code requirement.

Q: What's the difference between a hallway and a cased opening?

A: A cased opening has a 12" max. depth per MCCE.





Hallway: 3'-o" min.

Cased opening: 2'-6" max. up to 12" deep

Means of egress R302.7

#### Stairs:


 The code requires limited ½" gypsum protection on the underside of stairs when the space below is enclosed.





Stairs rise R311.7.3, R311.7.5.1


•Vertical rise 12'-3" max. with no landings.













#### Stairway headroom R311.7.2 exception #1


- This exception allows us to have a ceiling offset of 4 3/" maximum, without being considering it a projection into the required stairway headroom.
- This exception only applies at the side of stairs.






# Section R311.7.4 Walkline, was deleted from the NCRC. Because sections 311.7.5.2.1 (winder threads) and section R311.7.10.1 (spiral stairways) continue to reference the walkline we must borrow the definition from the NCBC. R201.3 Terms defined in other codes. Where terms are not defined in this code such terms shall have the meanings ascended not one code publications of the North Carolina Building Code Council.







Mezzanines
R325

NEW

Mezzanine section.

The requirements are similar to the commercial code.

Bowed thread stairways R311.7.10.3

- At no point shall the tread be less than 9".
- Each bowed tread is uniform with other bowed treads with no more than 3/8-inch variance.



# Ship's ladders

- A ship's ladder cannot be used as an element of a means of egress.
- Must be at least 20" wide, as measured at and below handrails.
- Handrails shall be provided on both sides, be continuous and graspable, per code.




Ramps R311.8


- Section R311.8 states the code requirements for ramps when they are used to access, or are located, within a dwelling.
- Egress ramp: 1:12 slope, two handrails.
- Non-egress ramp: 1:8 slope one handrail. (new)
- Landings are 36" min. in the direction of travel.





Interior landings R311.7.6

- A floor or landing is required at the top and bottom of stairs.
- An exception to the landing requirement allows a door at the top of an interior flight of stairs, provided the door does not swing over the step.











3. Fall protection







NC Department of Insurance Office of the State Fire Marshal - Engineering Division 1202 Mail Service Center, Raleigh, NC 27699-1202 Guards On Retaining Walls Code: 2018 Residential Code Date: April 10, 2019 Section: R404.4 Question: When are guards required on retaining walls? Guards Section R404.4 requires engineering design for the following residential retaining walls and are Section Provist regulate engineering design for the forming residential retains therefore required to be permitted and inspected:


1. All retaining walls with an unbalanced condition exceeding 48 inches


2. All retaining walls that cross over property line


3. All retaining walls that support buildings and their accessory structures. R312.1 Section R312.1.1 states in part; "Guards shall be located along open-sided walking surfaces, including stairs, ramps and landings, that are located more than 30 inches (762 mm) measured vertically to the floor or grade below...." The Commentary for Section R312.1 states: "The guard provisions of this code address the issue of providing protection for occupants from falling off of any elevated walking surface." Guards complying with R312 must be included on any of the above mentioned retaining walls when the finished area on the high side of the wall is more than 30 inches above the grade below and part of an egress route or other dedicated walking surface.














**Emergency** escape and rescue windows R310.2.1

**Emergency** 


escape and

rescue

R310.2.1

windows

R310.2.1 Minimum opening area. Emergency and escape rescue openings shall have a minimum net clear openable area of 4 square feet (0.372 m2). The minimum net clear opening height shall be 22 inches (558 mm). The minimum net clear opening width shall be 20 inches (508 mm). Emergency escape and rescue openings must have a minimum total glazing area of not less than 5 square feet (0.465 m<sub>2</sub>) in the case of a ground floor level window and not less than 5.7 square feet (0.530 m2) in the case of an upper story window.



NC Department of Insurance Office of the State Fire Marshal - Engineering Division 1202 Mail Service Center, Raleigh, NC 27699-1202 919-647-0000

**Emergency Escape and Rescue Opening Minimum Size** 

Code: 2018 Residential Code

Date: April 9, 2019

Section: R310.2.1

What is the difference in the 4.0 square feet minimum net clear opening requirement and the minimum glass area requirement for emergency escape and rescue openings?

The 4.0 square feet minimum net clear opening refers to the opening required when the sash is in the fully open position. This opening is expected to be used by the occupant for emergency

The 5.0 and 5.7 minimum glass area requirement is the size of the window opening when all the sashes are removed. This opening size is based on the minimum required opening for a rescue worker to enter and remove an occupant. Also, it expected that the rescue worker has the equipment required to knock the sash(s) out for access. The 5.7 square feet opening size for the second and third floors is to account for the additional area needed to dismount a ladder and

NC Department of Insurance Office of the State Fire Marshal - Engineering Division 1202 Mail Service Center, Raleigh, NC 27699-1202

**Emergency Escape and Rescue Opening for Casement Windows** 

Date: April 5, 2019

Code: 2018 Residential Code

Section: R310

**Emergency** 

escape and

rescue

R310.2.1


windows


A particular casement window unit has two swinging sashes and one fixed pane between the two swinging sashes. At least one of the swinging sashes meets the code requirements for minimum height or width and net clear opening for an emergency escape and rescue opening. The mullions between the swinging sashes and the fixed pane are not vertical load bearing. Can the window unit as a whole be considered in the 5.0 sq. ft. first floor and 5.7 sq. ft. upper story glass area requirement or does each swinging sash or fixed pane have to be considered separately?


Answer:


The window unit can be considered as meeting the 5.0/5.7 sq. ft. requirement if in the estimation of the local inspector the mullion between the swinging sash and the fixed pane can be knocked out with a fireman's ax with no more effort than would be required to knock out a sash of a


This interpretation would also apply if the window were just two swinging sashes without a glass














Public Way


R310


Egress may be guaranteed through an
Easement or a CCR (Declaration of Covenants
, conditions and restrictions Agreement) in
MCCE.


















Safety Glazing










#### Other than tempered glass:

 Labels may be omitted where approved by the building official and an affidavit, certificate or other evidence is submitted indicating code compliance.

#### Tempered spandrel glass:

 A manufacturer can identify safety glazing with a removable paper designation, provided removal would destroy the designation. This ensures that the designation will not be applied to a noncomplying piece of glass.



#### NC Department of Insurance Office of the State Fire Marshal - Engineering Division 1202 Mail Service Center, Raleigh, NC 27699-1202 919-647-0000

#### Glazing Labeling in Hazardous Locations

Code: 2018 NC Residential Code

Date: March 22, 2019

Section: R308.1

#### Question:

Is Section R308.1 referring to the glazing or the label being destroyed when removed?

#### Answer:

It is referring to the label itself and not the glazing. According to the 2015 IRC commentary, "A manufacturer can identify safety glazing with a removable paper designation, provided removal would destroy the designation. This ensures that the designation will not be applied to a noncomplying piece of glass".

Multi-pane assemblies R308.1.1



- Allows labeling of only one pane of glass when the exposed area of each pane is ≤1 sf.
- All other panes must be labeled either "16 CFR 1201" or "ANSI Z97.1

Impact load test required R308.3 The code requires that glazing in hazardous locations subject to human impact, pass impact tests.


#### Exceptions:


- 1. Louvered windows and jalousies meeting the thickness and length limitations in Section R<sub>3</sub>08.2.
- 2. Mirrors or glass hung on a wall or fitted with a backing.
- 3. Glass block constructed in accordance with Section R610.
































NC Department of Insurance Office of the State Fire Marshal - Engineering Division 1202 Mail Service Center, Raleigh, NC 27699-1202 919-647-0000 Tempered Glass Next to Doors Code: 2018 Residential Code Date: March 22, 2019 Section: R308.4.2 2.Near doors R308.4.2 **Ouestion:** If a window is located within 24" of a door, is tempered glass required? Answer: Yes, if the glazing is in the same plane as the door and the bottom edge of the glazing is less than 60 inches above the floor. No, if the glazing is not in the same plane as the door or the bottom edge of the glazing is 60 inches or more above the floor.


Decorative glazing.
 Intervening wall or other permanent barrier between door and glazing.
 Access through door is to closet or storage area ≤ 3 ft. in depth.
 Glazing that is adjacent to the fixed panel of patio doors.



































- Because site-built windows are not constructed in a manufacturing facility that follows industry standards, they must be constructed in accordance with Section 2404 of the IBC.
- Section2404 sets the required wind, snow, seismic and dead loads on glass.





- Glazing installed in roofs or walls that are on a slope **15 degrees or more** from the vertical.
- The is to protect occupants from the possibility of falling glazing materials.

# Skylights & slopped glazing materials R308.6.2



- Laminated glass
  - o.o15" polyvinyl butyral interlayer
  - <16 sf. area
  - Highest point is at 12 ft. af.f. max.
- Fully tempered glass (with screen protection).
- **Heat-strengthened glass** (with screen protection below).
- Wired glass.
- Approved rigid plastics.



- Screens must support the weight of the glass.
- The screen and its fastenings must be capable of supporting twice the weight of the glazing.

# Greenhouses R308.6.6

- The glazing regulations for greenhouses are less stringent because greenhouses are seldom occupied during storms that might break the glass.
- Screens are not required for sloped areas of greenhouses if the ridge of the greenhouse is not more than 20 feet above grade.

# Questions?

**Q:** How do we know which interpretations by DOI are formal and which ones are informal?

**A:** All interpretations posted on DOI are considered formal and shall be accepted by MCCE or any other jurisdiction. If an interpretation is deemed informal by DOI, it will be noted as such.

# Next Meeting: Code Connection - HBA July 3<sup>th</sup>

Thank you

Please e-mail topics to:

eurilynn.caraballoluccioni@mecknc.gov